



31 Lagavar Road, Ballintoy, Ballycastle, Ballycastle, BT54 6NG  
028 2076 2613

## Deutz-Fahr 6 series |



HP: 156 - 226

<b>Transmission:</b>	Manual
<b>Engine Size:</b>	6000